

# CARE AND MAINTENANCE

## NX SUPERGLOSS

NX Supergloss is supplied with a protective film in which should not be removed until all trade work has been completed. Once the protective film has been removed, it initiates the “curing” process, which takes approximately 72 hours to complete the hardening process of the surface. During this “curing” period, the acrylic material is more vulnerable to micro scratching, therefore it is important to carry out the correct cleaning procedure to avoid any damages to the surface.

It is highly recommended upon the removal of the protective film that the following procedure is to be strictly adhered to:

1. Use **Vuplex** - shake well and lightly spray on to the surface of the panel
2. Use **Microfiber cloth** to wipe using a light circular motion

This will remove any residue left from the protection film and shorten the "curing" process duration. Therefore, please avoid cleaning the surface again 72 hours of the initial cleaning.

### **WARNING:**

It is advised to avoid using these products below:

- Alcohol based cleaner
- Solvent based cleaner
- Abrasive cleaner
- Acetone
- Turpentine
- Petrol, pinewood and oil based cleaner
- Glass cleaner
- Cloth other than micro fibre cloth